

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaseT Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)



ATZ HDBT-E70-WPVD-M is a multiple functional switcher that switches input from different formats onto a display via HDBaseT.

It supports MANUAL, AUTO and PRIORITY three different working modes for input source switching. On MANUAL mode, it is able to select the input between HDMI, VGA and DP easily only by push SEL button. On Auto mode, it able to automatically detect and switching input signals from HDMI VGA and DP based on manual selection or last connected input. On priority mode it able to set the priority input source.

It supports 1xDP, 1xHDMI and 1xVGA+3.5mm audio inputs, 2xProgramming(RS232) ports, bi-directional IR over single HDBaseT(RJ45) output. Users will be able to use P1/P2 buttons to control the other equipment via RS232 control commands.

With the POC(power over cable) function, power only required at either end of Sender or Receiver. For the transmission distance it can support 1080p@60 up to 70m at, and 4K@30Hz up to 40m. It's popularly used in the small meeting room,

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaseT Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

classroom or other long distance transmission applications.

### Features:

- Supports 1080P 3D, and up to 4K30
- Supports HDCP1.4
- Transmission distance: 70m at 1080p@60, 40m at 4K@30 via Cat5e/Cat6
- Supports bi-directional IR
- Supports POC(power over Cable), POE function
- Supports RS232 programming
- Support manual, auto and priority working modes
- LED working indicator

### Specifications:

Input	1x DP, 1x HDMI, 1x VGA+3.5mm audio, 2x IR, 2x Programming
Output	1x HDBaseT(RJ45)
Control	Button, RS232
Transmission distance	70m at 1080P@60, 40m at 4K@30 via Cat5e/Cat6
Bandwidth	10.2Gbps
Power Supply	DC 12V 1.5A
Dimension (WxHxD)	Product weight: 88*88*33mm
	Packing dimension: 204*151*60mm
Weight	Product net weight: 195g
	Packing weight: 450g

**Model** : ATZ HDBT-E70-WPVD-M



**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

Operating Temperature	-10°C to 40°C
Storage Temperature	-25°C to 55°C

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/ Programming(70m)

**Panel:**



No	Name	Functions
<b>Indicator</b>	VGA	VGA signal indicator, flashing means connected, stable light selected
	HDMI	HDMI signal indicator, flashing means connected, stable light selected
	DP	DP signal indicator, flashing means connected, stable light means being selected
	LINK	Stable light means connected with Receivers successfully
	MANUAL	When this indicator lights up, can press "SEL" to select the input sources manually
	AUTO	Press and hold "SEL" for 5 seconds will enter auto mode
	PRIOR	Press and hold "SEL" for 5 seconds will enter Priority mode
	POWER	When power either by adapter or POC from Rx will light up
<b>Buttons</b>	P1	Programming button one to control other equipment
	P2	Programming button two to control other equipment
	SELECT	Signals switching between VGA, HDMI and DP and working modes settings
<b>Ports</b>	VGA PORT	Female VGA input port

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaseT Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

	HDMI PORT	Female HDMI input port
	DP PORT	Female DP input port
	AUDIO	3.5mm audio embedded for VGA input
	IR Tx	IR transmitter port
	IR Rx	IR receiver port
	RS232	RS232 programming or control port
<b>Rear Panel</b>	OUT	POC out
	IN	POC IN
	POC	PoC function jumper
	POE	POE function jumper
	B	12V POC jumper
	R	24V POC jumper

### Switching mode instruction

How to choose the working mode: After long push the SEL button until it change black, release. One of the mode lights will up, sequence: Manual > Auto > Priority.

#### Manual mode:

On manual mode, the light besides MANUAL will change to red. The other 2 modes light will remain black.

Press SEL to choose HDMI/ VGA/ DP input source. Sequence: HDMI > VGA > DP

#### Auto mode

On auto mode, the light besides AUTO will change to red. The other 2 modes light will remain black.

The input source whichever last active will take over the output display. Once unplug, it will jump to next input source. Sequence: HDMI > DP > VGA

#### Priority mode

**A. On priority mode, the light besides will change to red. On this mode only the priority input source can take over the output display.**

If unplug this priority input, the other input sources can't take over the output display.

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaseT Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)


## B. How to choose the priority input source:

Steps: After long push the SEL button until it change black, need to wait it to light up with blue again, then only release, it will then switch the prior port to another one.  
Sequence: HMDI > DP > VGA.

## RS232 settings

### 8.1 Connect serial cable.

Will need to use the RS232 cable connect wallplate to PC, open App SW31, will pop up below interface: default baud rate is 115200, users have to choose the correct COM port, then click "OK".



Connect Setting


Connect Type:	Serial
Port Select:	COM1
Baud Rate:	115200
Stop Bits:	1
Odd/Even:	none

OK  
Cancel

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

Will see below software interface



**8.2 Click button 11 to connect serial port, Refresh button will change to black after connect successfully.**

### 8.3 Load default setting;

After connect successfully then click button 13 to load wallplate's default settings ( Icon 13 will change to black means load succeed).

Switch below input sources to check if load successfully.



**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/ Programming(70m)

### 8.4 System setting

1. Select PC'S baut rate. ( Front Baudrate:  , default baud rate is 115200, if want to revise baut rate, need to reopen the APP).
2. Back baud rate stands for third party device's baud rate. Users select it accoring to the actual device.


### 8.5 Message setting

1. P1/ P2 ; Type in the command in box **16** and **17**, then click **SET** to save. After save, click **refresh** to check save successfully or not.
2. Support Hex and ASCII two formats command. Depend on user's demand to select whether need.


To tick  HEX Format(Two Char Per Byte) and  End [CR] .

### 9. Function and instruction:

- 1: Input source select : HDMI, VGA, DP;
- 2: EDID setting for input: HDMI, VGA, DP;
- 3: EDID Select drop-down column: Bypss EDID), Edid1,Edid2,Edid3,Edid4,Edid5,Edid6,Edid7,( from 1 to 7is bypass EDID)



- 4: HDCP: Disable or Enable





**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

5: CEC feature: Disable or Enable;

CEC Enable:	<input type="button" value="v"/>
Debug Message:	<input type="button" value="Disable"/> <input type="button" value="Enable"/>

6 :Select the baud rate for PC software configuration (Reopen the software after selection) : 2400, 4800, 9600, 14400, 19200, 38400, 57600, 115200;

Local Baudrate:	<input type="button" value="v"/>
Remote Baudrate:	<input type="button" value="2400"/> <input type="button" value="4800"/> <input type="button" value="9600"/> <input type="button" value="14400"/> <input type="button" value="19200"/> <input type="button" value="38400"/> <input type="button" value="57600"/> <input type="button" value="115200"/>
Format (Two Char Per	

7: P1P2 output baudrate selecton: 2400, 4800, 9600, 14400, 19200, 38400, 57600, 115200;

Remote Baudrate:	<input type="button" value="v"/>
	<input type="button" value="2400"/> <input type="button" value="4800"/> <input type="button" value="9600"/> <input type="button" value="14400"/> <input type="button" value="19200"/> <input type="button" value="38400"/> <input type="button" value="57600"/> <input type="button" value="115200"/>
Format (Two Char Per	

8: Hex and ascii two command formats for selection, put a tick in to box chose Hex;

HEX Format (Two Char Per Byte)

9: Presh Set to save P1,P2command;

10: Send command latency, usually measured in millisecond


Delay second
<input type="text" value="0"/>
<input type="text" value="0"/>

11: Serial port connection button;

**Model** : ATZ HDBT-E70-WPVD-M


**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

12: Serial port, baud rate, stop bit (default 1) , Verify (default none) ;




13: Click Refresh to load the configuration information of the wallplate into the software, after onnect succeed Refresh will change to black, if not this button will remail grey;

Button in gray stands for Connect failed



Button in black stands for Connect succeed



14: Label input box: ( **No actual function in this model**)

NoSync SendMessage:

15: Label input box: ( **No actual function in this model**)

SyncOn SendMessage:

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaset Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)


16: Command I input box:

P1 SendMessage:

17: Command II input box:

P2 SendMessage:

18: EDID select: Displayer( Terminal display equipment's EDID), push button 19 to Read EDID, will be shown in the box




20: Write EDID:  ;


21: Import EDID:  ; Click to open the below dialog box , EDID file format is ". Bin";


**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaseT Sender Wall Plate for HDMI/VGA/DP/Audio/IR/ Programming(70m)

After opening the EDID file, press the 20 (write) key to write the EDID information into the customized edid list 1 to 15.



22: Export EDID: ; Save the file as ". Bin" type. Press the export key to open the following dialog box, which can save the EDID information read back from the display device;



23: No actual function in this model.

**Model** : ATZ HDBT-E70-WPVD-M

**Description** : HDBaseT Sender Wall Plate for HDMI/VGA/DP/Audio/IR/  
Programming(70m)

---

### **Package contents:**

1x DP+HDMI+VGA Wallplate Transmitter  
1x Power adapter  
1x IR TX cable  
1x IR RX cable  
1x User Manual

---

### **Warranty: 2 Years**

Warranty is effective from the date of original delivery.

This warranty shall be void if a serial number has been removed from the product.